



CM 801 Mega Snake™ Installation Instructions

Thank you for purchasing Mega Snake, Snake Tray's newest cable management solution. Mega Snake is so quick and easy to install we want to be sure you reap the benefits of its quick installation.

To suspend Mega Snake™ or hang additional accessories from Mega Snake:

Mega Snake (CM 801 Series) has built-in Snake Rails™ used to secure 3/8" threaded rod to suspend the tray from above as well as mounting accessories to the tray system. Thread the upper nut to the desired installation height for the Mega Snake tray system. Next slide a flat washer on the threaded rod followed by the Mega Snake tray section. Install a lower flat washer and nut below the Mega Snake and tighten. That's it - no strut or additional hardware required.



To connect the sections of Mega Snake™ together:

Mega Snake straights, turns or intersections are joined together using the Mega Snake splice kit (Part number CM 801-18-SP or CM 801-24-SP). This kit provides you with a splice that mounts to the Snake Rail™ on both side of the tray system. To install simply align the tray sections and install the bottom splice plate with weld studs through the two tray sections. Install the upper splice plate over the studs and secure with supplied nuts.

